# MUELLER® GAS

2"-4"
H-10917
Slide Gate
Valves

### **WARNING:**

- Read and follow instructions carefully. Proper training and periodic review regarding the use of this equipment is essential to prevent possible serious injury and/or property damage.
- Do not exceed the pressure ratings of any components or equipment. Exceeding the rated pressure may result in serious injury and/or property damage.
- 3. Safety goggles and other appropriate protective gear should be used. Failure to do so could result in serious injury.
- 4. Pressure test, check for and repair leaks in all fittings and components each time one is installed or any joint or connection is broken. Failure to find and repair a leak from any source in the fittings, by-pass lines or equipment could result in an explosion and subsequent serious injury and/or property damage.



### **Reliable Connections**

Customer Service Center
Decatur, Illinois
800.798.3131
www.muellergas.com
moreinfo@muellercompany.com

All warranties, expressed or implied, for Mueller Drilling Machines are rendered null and void if the machines are used with shell cutters or equipment manufactured by someone other than Mueller Co.

# 2"- 4" H-10917 Slide Gate Valves

## **Repair and Maintenance Instructions**

### **GENERAL**

### Overview

Mueller Co. model H-10917 Slide Gate Valve is commonly used in many small diameter line stopping applications. The newest model incorporates many upgrades, providing ease of use and field maintenance.

### **Features**

- High strength aluminum body reduces weight by up to 40% depending on size.
- Replaceable Steel threads provide easy field replacement if damaged.
- O-ring seals deliver leak-free operation and simple maintenance.
- · Low Profile
- 275psig

### REPAIR INSTRUCTIONS

- **1.** Disassemble the upper and lower adapters.
- 2. Remove screws and handle block.
- **3.** Remove screws and separate the two valve bodies.
- **4.** Separate gate and the operating square from the lower valve body.
- **5.** Replace the O-rings on the adapters, on the valve bodies, and on the operating square.
- 6. Before assembling the new O-rings, carefully clean the area with Paint Thinner. Clean the new O-rings with a cloth wetted with alcohol. After the cleaning do not touch the O-rings with dirty hands to prevent contamination.

Note: The main body O-ring should be pressed into position at (4) points then followed from point to point for final insertion. The O-ring should be inserted into the groove dry, then lubricant applied to the gate and/or top side of the O-ring.

- After assembling the O-rings, let the air exit by slightly pressing on the O-ring with a small blunt screwdriver.
- **8.** Lubricate the gate sliding surface, the gate itself and the operating square with SKF LGMT 2 (or equivalent) grease.
- **9.** Place the gate in its sliding seat onto the lower valve body matching the operating square with its corresponding seat.
- **10.** Re-assemble the upper valve body and the lower and upper adapters.

# 3

### **PARTS LIST**

ID	DESCRIPTION	PART#
1	Lower & Upper Adapter	2" – 313089
		21/2" - 313090
		3" – 313092
		4" – 313093
2	Equalization Valve	683020
3	Upper Valve Body (Non-Replaceable Part)	
4	Handle Block Kit*	360166
5	Replacement Handle	313102
6 & 7	Replacement Gate	2" – 313107
	Operating Square Included with Gate	21/2" - 313108
		3" – 313109
		4" – 313110
8	Lower Valve Body (Non-Replaceable Part)	
9 – 13	O-Ring Kit	2" – 313111
		21/2" - 313112
		3" – 313113
		4" – 313114
14	Handle Retaining Screw	313131
15	Screw (Non-F	Replaceable Part)
16	Screw	313117
17	Screw	313118
18	Screw	2"- 313119
		21/2" - 313119
		3" – 313119
		4" – 313120

<sup>\*</sup>Handle Block Kit includes parts 4, 14 and 16.

NOTES: O-ring Kits include all O-rings for main valve. Equalization Valves are sold complete. Individual parts of the Equalization Valves are not available for purchase. For H-10917 Valves yellow in color (Pre-2015), please contact Customer Service for repair parts.



Gas (North America) 1.800.798.3131 www.muellergas.com moreinfo@muellercompany.com

International 1.423.490.9555 www.mueller-international.com international@muellercompany.com