



Reliable Connections™

580904 Cutter Arbor

Assembly Instructions

To Assemble:

1. Back out 2 set screws in Driver to clear Shank undercut. Remove Driver from Shank.
2. Install Driver to Shell Cutter.
3. Thread the Shank through the Driver into the Shell Cutter and tighten.
4. Tighten 2 set screws in Driver against Shank.
5. Install Pilot Drill and tighten set screw.

To Disassemble:

1. Remove Pilot Drill.
2. Loosen 2 set screws in Driver to clear Shank undercut.
3. Unscrew Shank from Shell Cutter.

Phone: (800) 798-3131

By deviating from the above listed instructions, you will void any product warranty and release Mueller Co. and its affiliated entities from any and all liability associated with the installation or use of this product. For details on the product's warranty, terms, and conditions, please visit www.muellergas.com.

© 2016 Mueller Co., LLC. All rights reserved.

Form 11952 09/16